

DYNASTAR I/O MODULE KIT - 06401-004-76-13



WARNING: This part *should* be installed only by qualified service personnel to reduce the risk of electric shock, serious injury, or fire. A plumbing permit and the services of a licensed plumber and electrician *might* be required in some areas.

Turn off the power supply and place the dishwasher disconnect (if applicable) in the off position. Lockout/tagout to prevent the power supply from being turned back on inadvertently.

CAUTION: Failure to install this part within the guidelines might adversely affect safety, performance, component life, and warranty coverage.

TOOLS REQUIRED

- 5/32" Allen Wrench
- Phillips Screwdriver


PARTS INCLUDED

QTY	DESCRIPTION	PART NUMBER
1	I/O Module	05945-005-01-56
1	Instructions, DynaStar I/O Module Replacement	07610-004-76-14

I/O MODULE REPLACEMENT

1. Remove both front panels using 5/32" allen wrench.

5/32" allen wrench used in this step.




I/O MODULE REPLACEMENT



CAUTION! Pictures showing wires are examples. Take note/picture of actual wires on machine for reference.


2. Locate I/O module on control panel and take note/picture of how wires are connected.



3. Remove wires.



4. Remove old I/O module using phillips screwdriver.



Phillips screwdriver
used in this step.

I/O module from kit
used in this step.

5/32" allen wrench
used in this step.

5. Place new I/O module from kit in the same place, oriented the same way, and secure using phillips screwdriver and hardware removed in last step.
6. Connect wires to new I/O module (reference note/picture taken in Step 2).
7. Replace front panels using 5/32" allen wrench.

I/O MODULE REPLACEMENT


To access programming, machine must be on and not in cycle.

Programming buttons (Up-arrow, Down-arrow, and Select) are hidden on display and are shown here as red outlines.

If HH-E model, skip to Step 17. If not HH-E, Steps 10–16 must be performed!

Only "Internal" will show at first, it scrolls to display "LLC."


8. Restore power to machine.
9. Turn machine on by pressing Power Button.




10. If HH-E model, skip to Step 17. Press and hold hidden Up-arrow and Down-arrow Buttons until "Setup" starts flashing (2–3 seconds).



11. Press hidden Select Button.



12. Press hidden Up-arrow Button repeatedly until "Internal LLC" appears.



13. Press hidden Select Button.

I/O MODULE REPLACEMENT


Programming buttons (Up-arrow, Down-arrow, and Select) are hidden on display and are shown here as red outlines.

14. Press hidden Up-arrow Button until "Off" appears in bottom display.



15. Press hidden Select Button.

16. Press Delime Button to exit.




17. Press and hold I and III Buttons until "Program" starts flashing (2–3 seconds).



If HH-E model, skip from Step 9 to Step 17!

18. Press hidden Select Button.

19. Use hidden Up-arrow or Down-arrow Button to change program number to correct number in table, based on model.



Pgrm #	Model
2	DynaStar
3	DynaStar VER
4	DynaStar NB

20. Press hidden Select Button ("Program" will flash).

21. Press Delime Button to exit.

22. Machine is now ready for operation.