

1. Turn off and disconnect all power to unit.
2. Cut drain hose 5" from diverter valve.
3. Attach drain quench to drain hose.
4. Attach rest of drain hose to other end of drain quench.
5. Drill 1/4" hole in back of machine for mounting drain quench.
6. Attach control box to side of unit by drilling 1/4" holes.
7. Connect black wire to heater contactor—L1.
 - On Avenger HT-E: Connect black wire to incoming power supply on L1.
8. Connect white wire to heater contactor—L2.
 - On Avenger HT-E: Connect white wire to incoming power supply on L2.
9. Hook water line from solenoid to new drain quench
10. Insert thermostat probe into fitting on drain quench
11. Hook incoming water line to solenoid

