

FAN TIMER PROGRAMMING

DISHSTAR HT-E-SEER DELTA HT-E-SEER

PROGRAMMING



- 1. Apply power (120, 208, or 240 VAC) to A1 & A2 terminals.
- 2. Hold down SET and ADJ buttons for at least 3 seconds.
- 3. Repeatedly press ADJ button until letter "F" appears on left-hand side.
- 4. Press SET button.
- 5. Verify letter "S" is flashing.
- 6. Press SET button.
- 7. Press ADJ button to adjust first digit (minutes) to "0".

- 8. Press SET button.
- 9. Press ADJ button to adjust second digit (tens of seconds) to "4".
- 10. Press SET button.
- 11. Press ADJ button to adjust third digit (seconds) to "5".
- 12. Press SET button.
- 13. Press ADJ button so there is an arrow facing downward.
- 14. Press SET button.

TESTING

STEP	ACTION	RESULT
1.	Apply power (120, 208, or 240 VAC) to the A1 & A2 terminals.	Idle state.
2.	Make control signal connection at B1. No control signal is applied.	Remains in idle state.
3.	Apply control signal (logic high).	Relay closes (ports 15-18).
4.	Remove control signal (logic low).	Relay remains closed for 2.5 minutes.

NOTICE In Step 4, if control signal is reapplied while the relay is still closed, Step 3 will restart.